




Recommendations for use of VCI



Components must be clean and dry
wear gloves to avoid fingerprint-corrosion
During packaging, the temperature of the goods to be packed should be the same as the ambient temperature
The packaging must be closed and sealed <i>Avoid holes and damage; if these are present, seal them to prevent the entry of water</i>
For high bulk densities, VCI material must also be placed at the centre
Avoid direct contact between metal and wood / paper / cardboard
Also cover the top and bottom of intermediate layers with VCI material



Temporary Corrosion Protection with BioCor® VCI-film packaging



Packaging construction



Pack the components in a bag and place it in the shipping unit



Minimise excess air in the packaging



Then seal the BioCor® VCI bag